


Airyx NH₃ Open Path Compact v.100

SMART, STABLE, AND CALIBRATION-FREE AMONIA MONITORING



KEY FEATURES

- ACCURATE GAS DETECTION: NH₃, NO, SO₂ with proven DOAS technology
- **COMPACT & FLEXIBLE**: One system, multiple measurement paths
- **RUGGED & MOBILE**: Weatherproof (IP64)
- PLUG & PLAY SETUP: Motorized autoalignment for instant deployment
- CALIBRATION FREE: DOAS technology, no calibration gases, no drift

APPLICATIONS

- Air quality & workplace safety monitoring
- Agriculture emission
- Industrial emission & process control
- Fence line monitoring
- NH₃ spatial distribution analysis



Airyx webpage



Airyx Contact




DESCRIPTION

The system enables precise Open Path DOAS measurements of ammonia (NH₃) across multiple paths using multiple retro reflectors. A UV deuterium lamp (D2) provides the light source, while a compact spectrometer performs the spectral analysis. With its fully motorized telescope head, the OPC easily adapts to a wide range of applications.

TECHNICAL DETAILS

Optics	Mirror Telescope, Focal Length of 300mm			
Light Source	D2 Lamp			
Detectable Gases Limit of Detection /ppb	NH ₃	NO	SO ₂	Aromatic Compounds
[@ 100m path length, 5 min] depend on conditions such as visibility, path length	1	4	5.5	-
Path length to reflector	up to 150 m			
Time Resolution	up to 1 minute			
Compact Spectrometer	Spectral Range 190 to 310nm & Resolution (FWHM) < 0.5 nm Temperature Stabilized			
Motorization	Azimuthal (0 $^{\circ}$ to 360 $^{\circ}$) and Elevation (-40 $^{\circ}$ to 75 $^{\circ}$)			
Housing	IP64 Housing, Internal Heating, Dew Point Monitoring			
Control Unit	Integrated Embedded PC, WIN10 IOT			
Temperature Control	Heating & Cooling			
Additional Sensors	Elevation, Ambient Temperature and Pressure, Internal Dew Point			
Data Interfaces	Internal Data Storage, LAN, WiFi, Machine2Machine			
Power Supply / Consumption	24V, 80 W max.			





 $\textit{NH}_{3} \ \textit{Open Path Compact set up at the Federal Environmental Agency station Neuglobsow, Germany (left)}. \ \textit{Example data time series (right)}.$